


UTILITY


COLLECTION

SEGMENTS AND ADD-ONS TRANSFER AND STORAGE CART



PARTS

X1



X4



M16 SCREW CAPS

X1



FLAT KEY

X4



CASTERS

X4




M16 PREVAILING TORQUE NUTS

ASSEMBLY


1

Lift one side and assemble casters




2

Repeat same for other side



3

Add screw caps on caster screws.



YOUR ALL DONE, WAY TO GO!