






## SERVICE CART

### ASSEMBLY INSTRUCTIONS




PARTS




3X BHP PANEL  
L35.4" W20.8" | L90cm W53cm

OR




2X BHP PANEL  
L35.4" W20.8" | L90cm W53cm  
1XBHP PANEL WITH BUMPER SYSTEM  
L38.5" W24" | L97.5cm W60.5cm




1X GENUINE LEATHER HANDLE

OR



1X STAINLESS STEEL HANDLE




X6  
SERVICE CART SEGMENTS  
12" | 30cm



X2  
M16 ALLEN SCREWS



X1  
ALLEN KEY FOR M16




X2  
CASTERS




X2  
SERVICE CART SEGMENTS  
12" | 30cm



X2  
SCREW CAPS



X1  
FLAT KEY





X2  
CASTERS WITH BRAKES


1

Start by turning one panel on its side  
Screw the segments and tight the leather handle


\*If your cart includes stainless steel handle instead of a leather handle it should look like drawing 1.1




1.1 Screw the segments and tight the Stainless steel handle



2




3 Turn the cart upside down.




- 4** Screw the casters on and tighten them using the flat key. Casters with brakes should be aligned to the handle.


\*If your cart includes a bumper system it should look like drawing 4.1



**4.1**



**5**



**GREAT JOB, YOUR GOOD TO GO!**