




Pro Ice Bin

DRAINAGE INSTRUCTIONS



MAINTENANCE



Remove dust regularly using a microfiber cloth.
Plastic products will last longer if you clean them using just lukewarm water and mild soap.



Avoid the use of sponges



Strictly avoid using ethyl alcohol or detergents containing acetone, trichlorethylene, ammonia, hydrocarbon substances and any other solvents, even in small quantities.



Never scrape with razor blades or other sharp instruments.






1

TAP DRAINING


Connect the adapter with the hose to the tap till you hear the Click.

X1
DRAIN HOSE WITH
QUICK CONNECTOR





After connecting the hose, open the tap clockwise. It's recommended to use either a container or a drainage channel to drain water.

CLOSE



OPEN






2

SIPHON DRAINING

Insert the pump head into the ice bin. Make sure that the other end of the hose is lower than the pump head.

X1
SIPHON DRAIN PUMP



Shake the pump head up and down vigorously until water begins to eject from the other end of the hose. When the stream stabilizes, stop shaking and let the siphon effect empty the bowl.